



Fit the rear two bolts only from the outside and dont screw them in much.

Fit bracket back piece to outrigger with cut out shape at the bottom.

With the pole structure in the vertical position, hook the scanhead onto the two bolts that are loosely screwed in before fitting the other two bolts. Tighten all 4 bolts and then plug in the scanhead cable.

